

CDS50 Software Release Notes

Version 16

To update via network:

- Navigate to “Firmware Update” in the Settings Menu.
- Press OK.

To update via USB:

USA and Canada:

- Unzip the file named “20190711_CDS50_US_V16.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Rest of the world:

- Unzip the file named “20190711_CDS50_EUROPE_V16.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Fix list:

- 3062 – Add default layer option for SACD playback.

CDS50 Software Release Notes

Version 14

To update via network:

- Navigate to “Firmware Update” in the Settings Menu.
- Press OK.

To update via USB:

USA and Canada:

- Unzip the file named “20181113_CDS50_US_V14.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Rest of the world:

- Unzip the file named “20181113_CDS50_EUROPE_V14.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Fix list:

- 2787 – High res flac playback distortion on some files.

CDS50 Software Release Notes

Version 11

To update via network:

- Navigate to “Firmware Update” in the Settings Menu.
- Press OK.

To update via USB:

USA and Canada:

- Unzip the file named “B2BBB9DCC1CB.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Rest of the world:

- Unzip the file named “B2BBB9DCC1CB.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Fix list:

- 2757 - Improve input switching
- 2761 – Improve VFD life

CDS50 Software Release Notes

Version 9

To update via network:

- Navigate to “Firmware Update” in the Settings Menu.
- Press OK.

To update via USB:

USA and Canada:

- Unzip the file named “20180626_CDS50_US_V9.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Rest of the world:

- Unzip the file named “20180626_CDS50_EUROPE_V9.fup” and put onto a memory stick (so it is the only file on the stick).
- Turn on the CDS50 and wait for the unit to fully start.
- Insert the memory stick in the USB port, located in the rear of the CDS50.
- The upgrade file will be detected, then follow the VFD prompts.
- Once the update has been completed, remove the memory stick.

Fix list:

- 2759: Improved DAC unmute time