

Arcam ST60 Crestron Home Drivers

Introduction

This driver suite enables control of the Arcam ST60 products via Crestron Home. The zip file comprises of drivers (pkg files), below is an overview of each driver.

AvReceiver_Arcam_ST60_IP.pkg

This is the core Crestron Home driver. It provides access to the switching, volume and mute functionality of the device.

Driver installation

To install these drivers on a Crestron Home system they need to be 'Side loaded' into the processor. Please follow the steps below:

1. In Crestron Toolbox open File Manager and connect to your Crestron Home Processor.
2. Browse to the user/ThirdPartyDrivers/Import directory.
3. Drag the pkg files from the zip file into the Import directory.
4. In the Crestron home setup app go to settings and configure system.
5. In the setup area select Pair Device.
6. Select Drivers. **Please be aware you need to press the Drivers button for the drivers to refresh. If you are in a higher level press back until you can select 'Drivers'**
7. Find the control driver in the AV Receiver menu and the Extension driver in the AV Receiver Helper Category.
8. Add the drivers and configure as normal.

Updating Drivers

Please follow the process below to update your drivers.

1. Make a note of the configuration of your drivers in the Crestron Home App.
2. Remove **all** instances of the Arcam ST60 driver from the Crestron Home App.
3. Reboot the processor via the System settings button (Cog), System Configuration and then Reboot.
4. After the processor has rebooted follow the Driver installation process above.